

## CHARGING SYSTEM (1NZ-FXE)

190UI-01

### ON-VEHICLE INSPECTION

#### 1. INSPECT BATTERY

**NOTICE:**

**If the battery is dead, or "READY" does not light up, recharge the battery. Check the battery again before the vehicle is returned to the customer.**

(a) Check the appearance.

(1) Check that the battery is not damaged or deformed.

If damage or deformed, replace the battery ( the dedicated battery for Prius).