


FRONT FLOOR FOOTREST REPLACEMENT

7615P-01

HINT:

The installation procedures are the removal procedures in reverse order.

**1. REMOVE FRONT FLOOR FOOTREST**

- (a) Using a screwdriver, disengage the 2 clips and remove the footrest.

HINT:

Tap the screwdriver tip before use.