

BACK DOOR GARNISH

REPLACEMENT

HINT:

- The installation procedures are the removal procedures in reverse order.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03–2).
- 1. REMOVE BACK DOOR TRIM BOARD ASSY (See page 75–33)
- 2. REMOVE BACK DOOR GARNISH SUB-ASSY OUTSIDE
- (a) Disconnect the opener switch connector.
- (b) Remove the 4 nuts, 2 clips and garnish.





(c) Remove the 2 screws and back door opener switch from the garnish.

7615U-01