

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the page given for that circuit.

| DTC No. (See Page) | Detection Item | Trouble Area |
|-----------------------|---------------------------------------|--|
| B1241 (05-2088) | Door Control Switch Circuit Diagnosis | <ul style="list-style-type: none">• Power window regulator master switch assy (Door control switch)• Door control switch assy• Instrument panel J/B assy (Multiplex network body ECU)• Wire harness |