
## FRONT DOOR BELT MOULDING REPLACEMENT

7615S-0

## HINT:

- The installation procedures are the removal procedures in reverse order.
- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- 1. REMOVE FRONT DOOR INSIDE HANDLE BEZEL LH (See page 75–9)
- 2. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH (See page 75-9)
- 3. REMOVE DOOR PULL HANDLE (See page 75-9)
- 4. REMOVE FRONT ARMREST BASE PANEL UPPER LH (See page 75-9)
- 5. REMOVE FRONT DOOR TRIM BOARD SUB-ASSY LH (See page 75-9)
- 6. REMOVE OUTER REAR VIEW MIRROR ASSY LH (See page 75-9)



## 7. REMOVE FRONT DOOR BELT MOULDING

- (a) Put protective tape under the moulding.
- (b) Using a moulding remover, pry out the moulding as shown in the illustration.

## HINT:

Tape the remover tip before use.

2004 Prius - Preliminary Release (RM1075U)

Author: Date: 1099