

INSTALLATION

- 1. INSTALL AIR VENT MODE CONTROL SWITCH**
 - (a) Attach the 2 claws to install the mode control switch.
- 2. INSTALL BLOWER CONTROL SWITCH**
 - (a) Attach the 2 claws to install the blower control switch.
- 3. INSTALL AIR MIX CONTROL SWITCH**
 - (a) Attach the 2 claws to install the air mix control switch.
- 4. INSTALL AIR CONDITIONING CONTROL ASSEMBLY**
 - (a) Connect the connectors.
 - (b) Attach the 3 clips to install the air conditioning control.
 - (c) Install the 2 screws.
- 5. INSTALL RADIO RECEIVER ASSEMBLY (w/ Radio Receiver)** (See page [IP-10](#))
- 6. INSTALL NO. 1 INSTRUMENT CLUSTER FINISH PANEL CENTER** (See page [IP-10](#))
- 7. INSTALL NO. 2 INSTRUMENT CLUSTER FINISH PANEL CENTER** (See page [IP-10](#))
- 8. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**
- 9. CHECK SRS WARNING LIGHT**
 - (a) Check the SRS warning light (see page [RS-37](#)).

