

INSTALLATION

1. INSTALL TRANSMITTER BATTERY



NOTICE:

Take extra care when handling these precision electronic components.


- (a) Install a battery (lithium battery: CR2016) with the positive (+) side facing upward, as shown in the illustration.

NOTICE:

- Be careful not to bend the transmitter battery electrode during insertion.
- Keep the transmitter cover interior free of dust and oil.



- (b) Install the cover.



2. INSTALL DOOR CONTROL TRANSMITTER MODULE

3. INSTALL TRANSMITTER HOUSING COVER

- (a) Install the transmitter housing cover to the transmitter housing case.
- (b) Check that the transmitter's LED illuminates 3 times when the switch is pressed 3 times.

OK:

Transmitter's LED illuminates 3 times when switch is pressed 3 times.

