

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- The wireless door lock control system troubleshooting procedures are based on the premise that the power door lock system is operating normally. Check the power door lock system first before troubleshooting the wireless door lock control system (see page [DL-7](#)).
- Use these procedures to troubleshoot the wireless door lock control system.
- *: Use the intelligent tester.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 INSPECT BATTERY VOLTAGE

Standard voltage:

11 to 14 V

If the voltage is below 11 V, recharge or replace the battery before proceeding.

NEXT

3 PROBLEM SYMPTOMS TABLE

Result:

Result	Proceed to
Fault is not listed in problem symptoms table	A
Fault is listed in problem symptoms table	B

B

Go to step 5

A

4 OVERALL ANALYSIS AND TROUBLESHOOTING*

- (a) Operation Check (see page [DL-44](#))
- (b) DATA LIST / ACTIVE TEST (see page [DL-59](#))
- (c) Terminals of ECU (see page [DL-54](#))

NEXT

5	REPAIR OR REPLACE
---	-------------------

NEXT

6	CONFIRMATION TEST
---	-------------------

NEXT

END
