

**DTC****B2793****Transponder Chip Malfunction****DESCRIPTION**

This DTC is output when: 1) during key code registration, a key malfunction occurs; 2) the key code was unable to be registered properly.

DTC No.	DTC Detection Condition	Trouble Area
B2793	Transponder chip malfunction	Key

**INSPECTION PROCEDURE****1****REREGISTER KEY**

- (a) Clear the DTC (see page [EI-18](#)).
- (b) Reregister the key code with the transponder key ECU (see page [EI-5](#))
- (c) Check that the engine starts with the key.

**OK:****Engine starts.****NG****REPLACE KEY****OK****END**

DTC	B2794	Unmatched Encryption Code
-----	-------	---------------------------

DESCRIPTION

This DTC is output when a key with an incomplete key code is inserted into the ignition key cylinder.

DTC No.	DTC Detection Condition	Trouble Area
B2794	Key with incomplete key code is inserted	Key

INSPECTION PROCEDURE

1	REREGISTER KEY
---	----------------

- (a) Clear the DTC (see page EI-18).
- (b) Reregister the key code with the transponder key ECU (see page EI-5)
- (c) Check that the engine starts with the key.

OK:  
Engine starts.

OK

NG	REPLACE KEY
----	-------------

END
-----