



FOOTWELL LIGHT

ON-VEHICLE INSPECTION

1. INSPECT FOOTWELL LIGHT

- (a) Connect the battery's positive (+) lead to terminal 2 and the negative (-) lead to terminal 1, then check that the light comes on.

OK:

Light comes on.

If the result is not as specified, replace the light.