


DISASSEMBLY

HINT:

- Use the same procedures for the RH and LH sides.
- The procedures listed below are for the LH side.

1. REMOVE REAR COMBINATION LIGHT BULB

- (a) Turn the 3 bulbs in the direction indicated by the arrows and pull to remove them.



REASSEMBLY

HINT:

- Use the same procedures for the RH and LH sides.
- The procedures listed below are for the LH side.

1. INSTALL REAR COMBINATION LIGHT BULB

- (a) Turn the 3 bulbs in the direction indicated by the arrows to install them.

