BRAKE

GENERAL MAINTENANCE

INSPECT BRAKE LINES AND HOSES HINT:

Work in a well-lighted area. Turn the front wheels fully to the right or left before beginning the inspection.

- (a) Using a mirror, check the entire circumference and length of the brake lines and hoses for:
 - Damage
 - Wear
 - Deformation
 - Cracks
 - Corrosion
 - Leaks
 - Bends
 - Twists

P009958E01

- (b) Check all the clamps for tightness and the connections for leakage.
- (c) Check that the hoses and lines are not near sharp edges, moving parts or the exhaust system.
- (d) Check that the lines are installed properly and pass through the center of the grommets.

INSPECT FRONT BRAKE 2.

(a) Check the front brake pads and discs (see page BR-**42**).

INSPECT BRAKE LININGS AND DRUMS

(a) Check the brake linings and drums. Also check the brake linings of the parking brake.



