



# TIRE AND WHEEL

## RECOMMENDED TOOLS

	<p>09082-00040</p>	<p>TOYOTA Electrical Tester</p>	<p>-</p>
	<p>(09083-00150)</p>	<p>Test Lead Set</p>	<p>-</p>

# EQUIPMENT

Dial indicator with magnetic base	
Tire pressure gauge	
Torque wrench	
Wheel balancer	

