



# FRONT SEAT ASSEMBLY (for Manual Seat)

## COMPONENTS

SE




N\*m (kgf\*cm, ft.\*lbf) : Specified torque



N\*m (kgf\*cm, ft.\*lbf) : Specified torque

● Non-reusable part

SE



For Passenger Side



OCCUPANT CLASSIFICATION ECU

N\*m (kgf\*cm, ft.\*lbf) : Specified torque

● Non-reusable part

for Driver Side

SEAT POSITION  
AIRBAG SENSORSEAT SLIDE POSITION  
SENSOR PROTECTOR

8.0 (82, 71 in.\*lbf)