


动态稳定控制(DSC)系统 DYNAMIC STABILITY CONTROL (DSC) SYSTEM

O-a



156

<p>O-01 DSC HU/CM (F)</p>	<p>O-02 ABS WHEEL-SPEED SENSOR LF (F) 左前ABS轮速传感器</p>	<p>O-03 ABS WHEEL-SPEED SENSOR RF (F) 右前ABS轮速传感器</p>
<p>O-04 ABS WHEEL-SPEED SENSOR LR (R) 左后ABS轮速传感器</p>	<p>O-05 ABS WHEEL-SPEED SENSOR RR (R) 右后ABS轮速传感器</p>	<p>O-06 DSC OFF SWITCH (I) DSC OFF开关</p>
<p>O-07 STEERING ANGLE SENSOR (I) 转向角传感器</p>		