



B1-01 PCM (E2)




B1-29 燃油喷射 (前置主1) (E2)




B1-30 燃油喷射 (后置主1) (E2)




B1-31 燃油喷射 (前置从) (E2)




B1-32 燃油喷射 (后置从) (E2)




B1-37 辅助进气阀电机 (E2)




B1-33 燃油喷射 (前置主2) (E2)



B1-34 燃油喷射 (后置主2) (E2)



B1-35 计量式油泵开关 (E2)



B1-36 引擎水温传感器 (E2)

