

# TOYOTA CAMRY ELECTRICAL WIRING DIAGRAM

	Section No.	Page
(English)		
INTRODUCTION .....	A	5
HOW TO USE THIS MANUAL .....	B	6
ABBREVIATIONS .....	C	8
RELAY LOCATIONS .....	D	22
ELECTRICAL WIRING ROUTING .....	E	36
OVERALL ELECTRICAL WIRING DIAGRAM .....	F	101

	Location
ABS (ANTI-LOCK BRAKE SYSTEM) .....	20, 61-2
AIR CONDITIONER .....	35, 69-2
AUTO ANTENNA .....	26, 54-3
AUTOMATIC AIR CONDITIONER (3VZ-FE) .....	36, 68-2
BACK DOOR LOCK CONTROL (W/G w/o POWER WINDOW) .....	27-4
BACK-UP LIGHT .....	5, 6, 42, 43-7
CHARGING .....	1-4, 38-2
CIGARETTE LIGHTER AND CLOCK .....	23, 52-3
COMBINATION METER .....	34, 67-2
CRUISE CONTROL .....	25, 60-2
DOOR LOCK CONTROL .....	28-2
ECT AND A/T INDICATOR .....	5, 6, 42, 43-2
ELECTRONICALLY CONTROLLED HYDRAULIC COOLING FAN (3VZ-FE) .....	26, 54-2
ENGINE CONTROL .....	2, 3, 4, 39, 40, 41-2
FRONT WIPER AND WASHER .....	19-1, 59-2
HEADLIGHT .....	7, 8, 44-2
HEADLIGHT BEAM LEVEL CONTROL .....	10, 48-2
HEADLIGHT CLEANER .....	24-2, 44-4
HORN .....	19-4, 59-3
ILLUMINATION .....	13, 47-2
INTERIOR LIGHT .....	14, 15, 16, 17, 49, 50-2
LIGHT AUTO TURN OFF (G.C.C.) .....	29-2
LIGHT REMINDER BUZZER .....	18, 52-2
MOON ROOF .....	22-3, 38-3
POWER SEAT .....	29-3
POWER SOURCE .....	1~69-1
POWER WINDOW .....	21, 56-3
RADIATOR FAN AND CONDENSER FAN (5S-FE) .....	27, 62-2
RADIO AND PLAYER .....	30, 31, 32, 33
REAR FOG LIGHT .....	63, 64, 65, 66-2
REAR WINDOW DEFOGGER .....	22-2, 45-2
REAR WINDOW DEFOGGER AND MIRROR HEATER .....	53-2
REAR WINDOW DEFOGGER AND MIRROR HEATER .....	24-2
REAR WIPER AND WASHER (W/G) .....	18, 53-3
REMOTE CONTROL MIRROR .....	21, 56-2
SEAT HEATER .....	23-2
SRS (SUPPLEMENTAL RESTRAINT SYSTEM) (G.C.C.) .....	9-3
STARTING AND IGNITION .....	1, 37-2
STOP LIGHT .....	8, 9, 55-2
TAILLIGHT .....	11, 12, 46-2
THEFT DETERRENT AND DOOR LOCK CONTROL .....	57, 58-2
TURN SIGNAL AND HAZARD WARNING LIGHT .....	19, 51-2
UNLOCK AND SEAT BELT WARNING (G.C.C.) .....	29-2

English