05J2W–01

LOCATION




Door Control Receiver
Door Oscillator
Front RH
Electrical Key Antenna RH
Front Door Courtesy
Lamp Switch Assy RH
Electrical Key
Antenna LH
Rear Door Courtesy
Lamp Switch Assy RH
Back Door Lock
Switch
Door Oscillator
Front LH
Front Door Courtesy
Lamp Switch Assy LH
Room Oscillator
Electrical Key Antenna
Rear Door Courtesy
Lamp Switch Assy LH
Back Door Oscillator (Outer)
Back Door Oscillator (Inner)
P
B75931