

BASIC INSPECTION

When the malfunction is not confirmed in the DTC check, troubleshooting should be carried out in all the possible circuits considered as causes of the problem. In many cases, by carrying out the basic engine check shown in the following flowchart, the location causing the problem can be found quickly and efficiently. Therefore, using this check is essential in the engine troubleshooting.

1 CHECK BATTERY VOLTAGE

NOTICE:

Carry out this check with the engine stopped and power switch OFF.

	OK	NG
Voltage	11 V or more	Less than 11 V

NG → CHARGE OR REPLACE BATTERY

OK

2 CHECK IF ENGINE WILL CRANK

NG → PROCEED TO PROBLEM SYMPTOMS TABLE ON PAGE [05-33](#)

OK

3 CHECK IF ENGINE STARTS

NG → GO TO STEP 6

OK

4 CHECK AIR FILTER

(a) Visually check if the air filter is not contaminated dirt or oil.

NG → REPLACE

OK

5 CHECK IDLE SPEED (See page [14-1](#))

NG → PROCEED TO PAGE [14-1](#) AND CONTINUE TO TROUBLESHOOT

OK

PROCEED TO PROBLEM SYMPTOMS TABLE ON PAGE [05-33](#)

6 | **CHECK FUEL PRESSURE (See page 11-7)**

NG → **PROCEED TO PAGE 18-3 AND CONTINUE TO TROUBLESHOOT**

OK

7 | **CHECK FOR SPARK (See page 18-6)**

NG → **PROCEED TO PAGE 18-3 AND CONTINUE TO TROUBLESHOOT**

OK

PROCEED TO PROBLEM SYMPTOMS TABLE ON PAGE 05-33