

HOW TO PROCEED WITH TROUBLESHOOTING

Perform troubleshooting according to the following flowchart.

HINT:

- For further details, see the page given.
- The hand-held tester can be used at steps 3, 4, 7, 10 and 13.

1 | VEHICLE BROUGHT TO WORKSHOP



2 | CUSTOMER PROBLEM ANALYSIS (SEE PAGE 05-1210)



3 | CHECK DTC AND FREEZE FRAME DATA (SEE PAGE 05-1220)

(a) Record DTCs and freeze frame data.



4 | CLEAR DTC AND FREEZE FRAME DATA (SEE PAGE 05-1220)



5 | PROBLEM SYMPTOM CONFIRMATION

SYMPTOM DOES NOT OCCUR (GO TO STEP 6)

SYMPTOM OCCURS (GO TO STEP 7)

6 | SYMPTOM SIMULATION (SEE PAGE 01-37)



7 | CHECK DTC (SEE PAGE 05-1220)

(a) Recheck for DTCs.

HINT:

- Refer to the diagnostic trouble code chart when any DTCs are output.
- When any CAN communication system DTCs are output, perform troubleshooting on the CAN communication system first (see page 05-2628).
- When communication to the power steering ECU Assy is not established through the hand-held tester, inspect terminals SIL of the DLC3 and power steering ECU Assy and inspect the IG circuit of the power steering ECU Assy.

NORMAL SYSTEM CODE IS OUTPUT: GO TO STEP 8

TROUBLE CODE IS OUTPUT: GO TO STEP 9

8	PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1217)
---	---



9	DTC CHART (SEE PAGE 05-1226)
---	------------------------------



10	CIRCUIT INSPECTION (SEE PAGE 05-1227 TO 05-1241)
----	--



11	IDENTIFICATION OF PROBLEM
----	---------------------------



12	REPAIR OR REPLACE
----	-------------------



13	CONFIRMATION TEST
----	-------------------



END
