

## INSTALLATION


### 1. INSTALL PARKING BRAKE CABLE

- (a) Connect the cable to the backing plate and parking brake shoe lever.

(1) Pass the cable through the backing plate, and then connect the cable to the lever.

(2) Install the cable to the backing plate with the bolt.

**Torque: 8.0 N\*m (82 kgf\*cm, 71 in.\*lbf)**



- (b) Install the clamp and clamp bolt (labeled F) to the trailing arm.

**Torque: 6.0 N\*m (61 kgf\*cm, 53 in.\*lbf)**

**NOTICE:**

**Securely install the clamp.**

- (c) Install the clamp and clamp bolt (labeled E) to the rear suspension crossmember.

**Torque: 6.0 N\*m (61 kgf\*cm, 53 in.\*lbf)**

**NOTICE:**

**Securely install the clamp.**

- (d) Install the clamp and clamp bolt (labeled D) to the crossmember.

**Torque: 6.0 N\*m (61 kgf\*cm, 53 in.\*lbf)**

**NOTICE:**

**Securely install the clamp.**

- (e) Install the clamp and clamp bolt (labeled C) to the body.

**Torque: 6.0 N\*m (61 kgf\*cm, 53 in.\*lbf)**

**NOTICE:**

**Securely install the clamp.**

- (f) Install the casing cap and casing cap bolt (labeled B) to the body.

**Torque: 6.0 N\*m (61 kgf\*cm, 53 in.\*lbf)**


**NOTICE:**

**Securely install the casing cap.**

- (g) Install the cable clamp (labeled A) to the body.

**NOTICE:**

**Securely install the clamp.**



**2. INSTALL PARKING BRAKE EQUALIZER**

- (a) Connect the 3 cable ends to the equalizer.

**3. INSTALL REAR WHEEL**

**Torque: 103 N\*m (1,050 kgf\*cm, 76 ft.\*lbf)**

**4. ADJUST PARKING BRAKE LEVER TRAVEL (See page [PB-2](#))**

**5. INSTALL REAR CONSOLE BOX SUB-ASSEMBLY**

- (a) Install the rear console box (see page [IP-23](#)).

**HINT:**

Refer to the procedures from the installation of the rear console box sub-assembly up until the installation of the No. 1 console upper panel garnish.